



ULINE H-1166

L-BAR SEALER

1-800-295-5510
uline.com



#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Snap Bushing	1	-----	-----
2	Heater Post Bushing (Part of an Assembly)	2	H-1247-POST	POSTKIT
3	Roller Hinge	4	-----	-----
4	Heater Cover	2	H-1166-ENDCP	*ENDCAP-L
5	Handle	1	-----	*1313L-05
6	Roller	2	-----	*ROLLER12
7	Sealer Jaw	2	-----	-----
8	Platen Arm	1	-----	*1313L-08
9	Upper Jaw Support	2	-----	-----
10	Film Dispenser	1	-----	-----
11	Roller Bracket	2	-----	-----
12	Enclosure Cover	1	-----	*BD-1313L
13	Base Plate	1	-----	-----
14	Bottom Cover Plate	1	-----	-----
15	Platen Arm Bracket	2	-----	-----
18	Heater Assembly Plate Rectangular	1	H-1166-APLAT	*COPPERPL
19	Bolt For Spring	1	-----	-----
20	Screw For Handle	2	-----	-----
21	Screw For Jaw	4	-----	-----
22	Heater Post (Part of an Assembly)	2	H-1247-POST	POSTKIT
23	Rubber Foot	4	H-1166-23	*FOOT-F
24	Roller Base	1	-----	-----
25	Power Switch	1	-----	*ROCKSW
26	Limited Switch	1	-----	*MICRO-A
27	Transformer	1	H-1166-TR13	*TR1313L
28	Power Supply Cord	1	-----	*CORD-I
29	Heater Element	2	-----	ER1313L
30	Fuse Holder	1	-----	*FUSEBOXA
31	Power Bracket	1	H-1166-BRKT	*SOCKETI
32	Timer	1	H-1166-TIMER	*TI-1313L
33	Rubber For Lower Jaw	2	H-1166-33	*SR300AI
34	Rubber For Upper Jaw	2	H-1166-34	*SR2013I
35	Upper Teflon Sheet	2	-----	*TF1313L
36	Lower Heater Clothes	2	-----	*TFL1313L
37	Insulation Barrier	1	-----	-----
38	Heater Post Spring (Part of an Assembly)	2	H-1247-POST	POSTKIT
39	Return Spring	1	-----	*RE-SPR-I
40	Spring For Upper Jaw	4	-----	-----
41	C-Clip For Handle	4	H-1166CCLIP	C-CLIP
42	C-Clip For Heating Post	2	H-1166-CLIPP	CCLIP