



ULINE H-5484

HEAVY-DUTY PALLET TRUCK

1-800-295-5510
uline.com



FRAME DIAGRAM



FRAME DIAGRAM PARTS LIST

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Handle Assembly	1	H-5484-1	WB-HNDLASSY
2	Axial Compression	1	H-5484-SHAFT	WB-FRAME-PT2
3	Oil Pump	1	-----	WB-FRAME-PT3
4	Axle, Front Wheel	1	H-5484-4	WB-FRAME-PT4
5	Baffle Ring	1	-----	WB-FRAME-PT5
6	Circlip for Hole 95	1	H-5484-FPT6	WB-FRAME-PT6
7	Bearing 6012-2RS	2	H-5484-7	WB-FRAME-PT7
8	Support Seat	1	-----	WB-FRAME-PT8

FRAME DIAGRAM PARTS LIST CONTINUED

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
9	Circlip for Shaft 60	1	-----	WB-FRAME-PT9
10	Hexagon Bolt M8 x 70	1	-----	WB-FRAME-PT10
11	Bearing Cover	1	H-5484-FPT11	WB-FRAME-PT11
12	Backup Plate	1	-----	WB-FRAME-PT12
13	Thrust Ball Bearing 51112	1	-----	WB-FRAME-PT13
14	Spring Pin 5 x 28	22	H-5484-14	WB-FRAME-PT14
15	Locknut M8	1	-----	WB-FRAME-PT15
16	Inner Hexagon Screw M6 x 12	5	H-5484-16	WB-FRAME-PT16
17	Truck Frame	1	-----	WB-FRAME-PT17
18	Rocker Assembly 685	1	-----	WB-FRAME-PT18
19	Bearing 6204-2RS	12	H-1043-B9	B9
20	Big (Steering) Wheel	2	H-5484-20	WB-FRAME-PT20
21	Big (Steering) Wheel Hardware Kit Includes: • Half Cirque (4) • Bowl Washer (2) • Retaining Ring for Axle (2) • Dust Cover (2)	1	H-7274	WB-FRAME-PT21 WB-FRAME-PT22 WB-FRAME-PT23 WB-FRAME-PT25
24	Pin Roll 16 x 42	2	H-5484-24	WB-FRAME-PT24
26	Bushing 16 x 18 x 15	6	H-5484-26Q	WB-FRAME-PT26
27	Bushing 16 x 18 x 20	2	-----	WB-FRAME-PT27
28	Bushing 25 x 30	2	-----	WB-FRAME-PT28
29	Coupling Head	2	H-5484-CH29Q	WB-FRAME-PT29
30	Pin Roll 16 x 44	2	H-5484-PR30Q	WB-FRAME-PT30
31	Long Shaft 685 (No Hole)	1	-----	WB-FRAME-PT31
32	Circlip for Hole 25	2	-----	WB-FRAME-PT32
33	Connecting Rod 1220	2	H-5484-33	WB-FRAME-PT33
34	Pin Roll 16 x 100	2	H-5484-34	WB-FRAME-PT34
35	Pin Roll 20 x 158	2	H-5484-35	WB-FRAME-PT35
36	Bushing 20 x 23 x 25	4	H-5484-36	WB-FRAME-PT36
37	Wheel Carrier (Lower Place)	2	H-5484-37	WB-FRAME-PT37
38	Bushing 20 x 23 x 12	4	H-5484-38	WB-FRAME-PT38
39	Pin Roll 20 x 105	4	H-5484-PT39	WB-FRAME-PT39
40	Bracket Plate	4	H-5484-40	WB-FRAME-PT40
41	Circlip for Hole 47	8	H-5484-PT41	WB-FRAME-PT41
42	Fork (Load) Wheel	4	H-5484-42	WB-FRAME-PT42
43	Hexagon Bolt M6 x 50	2	H-5484-PT43	WB-FRAME-PT43
44	Entry (Roller) Wheel Black/White	2	H-5484-PT44	WB-FRAME-PT44
45	Locknut M6	2	H-5484-PT45	WB-FRAME-PT45
46	Steering Wheel Assembly	1	H-5484-SWA	WB-FRAME-PT2019


ULINE H-5484

HEAVY-DUTY PALLET TRUCK

1-800-295-5510
uline.com

HANDLE DIAGRAM

A



HANDLE DIAGRAM PARTS LIST

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
A	Handle Assembly Includes: • Cylindrical Pin #1 (1) • Spring Pin 3 x 20 #2 (1) • Pressure Wheel #3 (1) • Bushing 1220 #4 (1) • Pull Rod Unit #5 (1) • Bushing SF-1F2015 #6 (2) • Chain C-6-9-04A #7 (1)	1	H-5484-1	WB-HNDLASSY
1	Cylindrical Pin	1	H-5484-8	WB-HANDLE-PT8
2	Spring Pin 3 x 20	1	H-5484-9	WB-HANDLE-PT9
3	Pressure Wheel	1	H-5484-10	WB-HANDLE-PT10
4	Bushing 1220	1	H-5484-11	WB-HANDLE-PT11
5	Pull Rod Unit	1	H-5484-12	WB-HANDLE-PT12
6	Bushing SF-1F2015	2	H-5484-13	WB-HANDLE-PT13
7	Chain C-6-9-04A	1	H-5484-CHAIN	WB-HANDLE-PT14

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or sprayer. The components are numbered 1 through 41. The assembly is shown in a disassembled state, with parts arranged in a vertical column and exploded views to the left and right. The central part is a main body (14) with a handle (18) and a trigger gun (19). The handle is connected to a pump mechanism (15) which includes a piston (16) and a spring (17). The trigger gun (19) is connected to a nozzle (20) and a spray gun (21). The main body (14) has a top cap (6) and a bottom cap (7). The pump mechanism (15) has a piston (16) and a spring (17). The trigger gun (19) has a trigger (18) and a spray gun (21). The nozzle (20) is connected to the spray gun (21). The main body (14) has a top cap (6) and a bottom cap (7). The pump mechanism (15) has a piston (16) and a spring (17). The trigger gun (19) has a trigger (18) and a spray gun (21). The nozzle (20) is connected to the spray gun (21). The main body (14) has a top cap (6) and a bottom cap (7). The pump mechanism (15) has a piston (16) and a spring (17). The trigger gun (19) has a trigger (18) and a spray gun (21). The nozzle (20) is connected to the spray gun (21).

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Bowl Washer	1	H-5484-BWSHR	WB-PUMP-PT1
2	Spring Cap	1	H-5484-PT2	WB-PUMP-PT2
3	Spring	1	H-5484-SPRNG	WB-PUMP-PT3
4	Dustproof Ring 18	1	H-5484-PT4	WB-PUMP-PT4

PUMP DIAGRAM PARTS LIST CONTINUED

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
5	Y-Type Seal Ring 18	1	H-5484-PT5	WB-PUMP-PT5
6	Dustproof Ring 45 x 57	1	H-5484-PT6	WB-PUMP-PT6
7	Circlip for Hole 58	1	H-5484-PT7	WB-PUMP-PT7
8	O-Ring 58 x 3.55	1	H-5484-PT8	WB-PUMP-PT8
9	O-Ring 45 x 3.55	1	H-5484-PT9	WB-PUMP-PT9
10	Guiding Cover	1	H-5484-PT10Q	WB-PUMP-PT10
11	Pipe Sleeve	1	H-5484-PT11Q	WB-PUMP-PT11
12	Guiding Ring	1	H-5484-PT12Q	WB-PUMP-PT12
13	Seal Ring 45 x 55 x 7	1	-----	WB-PUMP-PT13
14	Plunger 45 x 289.5	1	-----	WB-PUMP-PT14
15	Thrust Ball Bearing 51106	1	H-5484-PT15	WB-PUMP-PT15
16	Screw Plug M10 x 1	2	H-5484-PT16	WB-PUMP-PT16
17	Combined Washer 10	2	H-5484-PT17	WB-PUMP-PT17
18	Lever Plate	1	H-5484-18	WB-PUMP-PT18
19	Slotted Set Screw with Cone Point M6 x 25	1	H-5484-SLSCR	WB-PUMP-PT19
20	Hexagon Nut M6	1	H-5484-NUTM6	WB-PUMP-PT20
21	O-Ring 10 x 2.65	1	H-5484-PT21	WB-PUMP-PT21
22	Firing Pin Set	1	H-5484-PT22	WB-PUMP-PT22
23	Combined Washer 20	2	H-5484-PT23	WB-PUMP-PT23
24	Firing Pin	1	H-5484-PT24	WB-PUMP-PT24
25	Spring 1.2 x 9.5 x 22	1	H-5484-PT25	WB-PUMP-PT25
26	Pressure Adjusting Screw M10 x 1	1	H-5484-PT26	WB-PUMP-PT26
27	Spring 2 x 8 x 16	1	H-5484-PT27	WB-PUMP-PT27
28	Ball Seat	1	H-5484-PT28	WB-PUMP-PT28
29	Steel Ball 5	1	H-5484-PT29	WB-PUMP-PT29
30	Tube Axle	1	H-5484-PT30Q	WB-PUMP-PT30
31	Inner Hexagon Screw M8 x 45	1	H-5484-PT31Q	WB-PUMP-PT31
32	Steel Ball 7	1	H-5484-PT32	WB-PUMP-PT32
33	O-Ring 10 x 2.65	1	H-5484-PT33	WB-PUMP-PT33
34	Cartridge Valve III	1	H-5484-PT34	WB-PUMP-PT34
35	Lock Rod	1	H-5484-PT36Q	WB-PUMP-PT35
36	Composite Bushing 20 x 23 x 25	1	-----	WB-PUMP-PT37
37	Ball Top	1	H-5484-PT38	WB-PUMP-PT38
38	Cylindrical Pin 4 x 25	1	H-5484-PPT39	WB-PUMP-PT39
39	Double Speed Pump Core Assembly	1	H-5484-DSPCA	WB-PUMP-PT40
40	Double Speed Pump Cylinder	1	H-5484-PT40	WB-PUMP-PT41
41	Copper Washer	1	H-5484-PMP41	WB-PUMP-PT42
	Pump Assembly	1	H-5484-PUMP	PUMPWB

ULINE H-5484

PATÍN HIDRÁULICO DE USO PESADO

800-295-5510
uline.mx





DIAGRAMA DE LA ESTRUCTURA



LISTA DE PARTES DEL DIAGRAMA DE LA ESTRUCTURA

#	DESCRIPCIÓN	CANT.	NO. DE PARTE DE ULINE	NO. DE PARTE DEL FABRICANTE
1	Ensamble del Asa	1	H-5484-1	WB-HNDLASSY
2	Compresión del Eje	1	H-5484-SHAFT	WB-FRAME-PT2
3	Bomba de Aceite	1	-----	WB-FRAME-PT3
4	Eje de Llanta Frontal	1	H-5484-4	WB-FRAME-PT4
5	Anillo Deflector	1	-----	WB-FRAME-PT5
6	Clip Redondo para Orificio 95	1	H-5484-FPT6	WB-FRAME-PT6
7	Balero 6012-2RS	2	H-5484-7	WB-FRAME-PT7
8	Base de Soporte	1	-----	WB-FRAME-PT8

ULINE H-5484

PATÍN HIDRÁULICO DE USO PESADO

800-295-5510
uline.mx

CONTINUACIÓN DE LISTA DE PARTES DEL DIAGRAMA DE LA ESTRUCTURA

#	DESCRIPCIÓN	CANT.	NO. DE PARTE DE ULINE	NO. DE PARTE DEL FABRICANTE
9	Clip Redondo para el Eje 60	1	-----	WB-FRAME-PT9
10	Perno Hexagonal M8 x 70	1	-----	WB-FRAME-PT10
11	Cubierta del Balero	1	H-5484-FPT11	WB-FRAME-PT11
12	Placa de Apoyo	1	-----	WB-FRAME-PT12
13	Balero de Empuje con Balines 51112	1	-----	WB-FRAME-PT13
14	Pasador con Resorte 5 x 28	22	H-5484-14	WB-FRAME-PT14
15	Tuerca de Seguridad M8	1	-----	WB-FRAME-PT15
16	Tornillo Hexagonal Interno M6 x 12	5	H-5484-16	WB-FRAME-PT16
17	Estructura del Patín	1	-----	WB-FRAME-PT17
18	Ensamble Oscilante 685	1	-----	WB-FRAME-PT18
19	Balero 6204-2RS	12	H-1043-B9	B9
20	Llanta Grande (de Dirección)	2	H-5484-20	WB-FRAME-PT20
21	Kit de Tornillería de la Llanta Grande (de Dirección) Incluye: • 4 Medio Anillos • 2 Rondanas Cónicas • 2 Anillos de Retención para el Eje • 2 Cubiertas para Polvo	1	H-7274	WB-FRAME-PT21 WB-FRAME-PT22 WB-FRAME-PT23 WB-FRAME-PT25
24	Pin de Rodillo 16 x 42	2	H-5484-24	WB-FRAME-PT24
26	Casquillo 16 x 18 x 15	6	H-5484-26Q	WB-FRAME-PT26
27	Casquillo 16 x 18 x 20	2	-----	WB-FRAME-PT27
28	Casquillo 25 x 30	2	-----	WB-FRAME-PT28
29	Cabeza de Acoplamiento	2	H-5484-CH29Q	WB-FRAME-PT29
30	Pin de Rodillo 16 x 44	2	H-5484-PR30Q	WB-FRAME-PT30
31	Eje Largo 685 (Sin Orificio)	1	-----	WB-FRAME-PT31
32	Clip Redondo para Orificio 25	2	-----	WB-FRAME-PT32
33	Clip Redondo para Orificio 1220	2	H-5484-33	WB-FRAME-PT33
34	Pin de Rodillo 16 x 100	2	H-5484-34	WB-FRAME-PT34
35	Pin de Rodillo 20 x 158	2	H-5484-35	WB-FRAME-PT35
36	Casquillo 20 x 23 x 12	4	H-5484-36	WB-FRAME-PT36
37	Porta Llanta (Parte Baja)	2	H-5484-37	WB-FRAME-PT37
38	Casquillo 20 x 23 x 12	4	H-5484-38	WB-FRAME-PT38
39	Pin de Rodillo 20 x 105	4	H-5484-PT39	WB-FRAME-PT39
40	Placa de Soporte	4	H-5484-40	WB-FRAME-PT40
41	Clip Redondo para Orificio 47	8	H-5484-PT41	WB-FRAME-PT41
42	Llanta de Horquilla (Carga)	4	H-5484-42	WB-FRAME-PT42
43	Perno Hexagonal M6 x 50	2	H-5484-PT43	WB-FRAME-PT43
44	Llanta de Acceso (Rodillo) Negro/Blanco	2	H-5484-PT44	WB-FRAME-PT44
45	Tuerca M6	2	H-5484-PT45	WB-FRAME-PT45
46	Ensamble de la Llanta de Dirección	1	H-5484-SWA	WB-FRAME-PT2019

ULINE

H-5484


PATÍN HIDRÁULICO

DE USO PESADO

800-295-5510

uline.mx

DIAGRAMA DEL ASA



LISTA DE PARTES DEL DIAGRAMA DEL ASA


#	DESCRIPCIÓN	CANT.	NO. DE PARTE DE ULINE	NO. DE PARTE DEL FABRICANTE
A	Ensamble del Asa Incluye: • Pin Cilíndrico #1 (1) • Pasador con Resorte 3 x 20 #2 (1) • Llanta de Presión #3 (1) • Casquillo para el Eje 1220 #4 (1) • Unidad de la Varilla de Apoyo #5 (1) • Casquillo SF-1F2015 #6 (2) • Cadena C-6-9-04A #7 (1)	1	H-5484-1	WB-HNDLASSY
1	Pin Cilíndrico	1	H-5484-8	WB-HANDLE-PT8
2	Pasador con Resorte 3 x 20	1	H-5484-9	WB-HANDLE-PT9
3	Llanta de Presión	1	H-5484-10	WB-HANDLE-PT10
4	Casquillo 1220	1	H-5484-11	WB-HANDLE-PT11
5	Unidad de la Varilla de Apoyo	1	H-5484-12	WB-HANDLE-PT12
6	Casquillo SF-1F2015	2	H-5484-13	WB-HANDLE-PT13
7	Cadena C-6-9-04A	1	H-5484-CHAIN	WB-HANDLE-PT14

ULINE H-5484

PATÍN HIDRÁULICO DE USO PESADO

800-295-5510
uline.mx

DIAGRAMA DE LA BOMBA



LISTA DE PARTES DE LA BOMBA

#	DESCRIPCIÓN	CANT.	NO. DE PARTE DE ULINE	NO. DE PARTE DEL FABRICANTE
1	Rondana Cónica	1	H-5484-BWSHR	WB-PUMP-PT1
2	Tapa del Resorte	1	H-5484-PT2	WB-PUMP-PT2
3	Resorte	1	H-5484-SPRNG	WB-PUMP-PT3
4	Anillo para Polvo 18	1	H-5484-PT4	WB-PUMP-PT4

ULINE H-5484

PATÍN HIDRÁULICO DE USO PESADO

800-295-5510
uline.mx

CONTINUACIÓN DE LISTA DE PARTES DE LA BOMBA

#	DESCRIPCIÓN	CANT.	NO. DE PARTE DE ULINE	NO. DE PARTE DEL FABRICANTE
5	Anillo de Sellado Tipo Y 18	1	H-5484-PT5	WB-PUMP-PT5
6	Anillo Contra Polvo 45 x 57	1	H-5484-PT6	WB-PUMP-PT6
7	Clip Redondo para Orificio 58	1	H-5484-PT7	WB-PUMP-PT7
8	Anillo Tórico 58 x 3.55	1	H-5484-PT8	WB-PUMP-PT8
9	Anillo Tórico 45 x 3.55	1	H-5484-PT9	WB-PUMP-PT9
10	Cubierta Guía	1	H-5484-PT10Q	WB-PUMP-PT10
11	Funda del Tubo	1	H-5484-PT11Q	WB-PUMP-PT11
12	Anillo Guía	1	H-5484-PT12Q	WB-PUMP-PT12
13	Anillo Sellador 45 x 55 x 7	1	-----	WB-PUMP-PT13
14	Émbolo 45 x 289.5	1	-----	WB-PUMP-PT14
15	Balero de Empuje con Balines 51112	1	H-5484-PT15	WB-PUMP-PT15
16	Tornillo Conector M10 x 1	2	H-5484-PT16	WB-PUMP-PT16
17	Rondana Combinada 10	2	H-5484-PT17	WB-PUMP-PT17
18	Placa de la Palanca	1	H-5484-18	WB-PUMP-PT18
19	Tornillo de Ajuste Ranurado con Punta Cónica M6 x 25	1	H-5484-SLSCR	WB-PUMP-PT19
20	Tuerca Hexagonal M6	1	H-5484-NUTM6	WB-PUMP-PT20
21	Anillo Tórico 10 x 2.65	1	H-5484-PT21	WB-PUMP-PT21
22	Set de Pin de Disparo	1	H-5484-PT22	WB-PUMP-PT22
23	Rondana Combinada 20	2	H-5484-PT23	WB-PUMP-PT23
24	Pin de Disparo	1	H-5484-PT24	WB-PUMP-PT24
25	Resorte 1.2 x 9.5 x 22	1	H-5484-PT25	WB-PUMP-PT25
26	Tornillo de Ajuste de Presión M10 x 1	1	H-5484-PT26	WB-PUMP-PT26
27	Resorte 2 x 8 x 16	1	H-5484-PT27	WB-PUMP-PT27
28	Base del Balín	1	H-5484-PT28	WB-PUMP-PT28
29	Balín 5	1	H-5484-PT29	WB-PUMP-PT29
30	Eje del Tubo	1	H-5484-PT30Q	WB-PUMP-PT30
31	Tornillo Interno Hexagonal M8 x 45	1	H-5484-PT31Q	WB-PUMP-PT31
32	Balín 7	1	H-5484-PT32	WB-PUMP-PT32
33	Anillo Tórico 10 x 2.65	1	H-5484-PT33	WB-PUMP-PT33
34	Válvula del Cartucho III	1	H-5484-PT34	WB-PUMP-PT34
35	Varilla de Seguridad	1	H-5484-PT36Q	WB-PUMP-PT35
36	Balero Compuesto 20 x 23 x 25	1	-----	WB-PUMP-PT37
37	Tapa Redondeada	1	H-5484-PT38	WB-PUMP-PT38
38	Pin Cilíndrico 4 x 25	1	H-5484-PPT39	WB-PUMP-PT39
39	Ensamble del Núcleo de la Bomba de Dos Velocidades	1	H-5484-DSPCA	WB-PUMP-PT40
40	Cilindro de la Bomba de Dos Velocidades	1	H-5484-PT40	WB-PUMP-PT41
41	Rondana de Cobre	1	H-5484-PMP41	WB-PUMP-PT42
	Ensamble de la Bomba	1	H-5484-PUMP	PUMPWB

ULINE H-5484

TRANSPALETTE

ROBUSTE

1-800-295-5510
uline.ca





SCHÉMA DE LA STRUCTURE



LISTE DES PIÈCES DU SCHÉMA DE LA STRUCTURE

#	DESCRIPTION	QTÉ	RÉF. ULINÉ	RÉF. DU FABRICANT
1	Ensemble De La Poignée	1	H-5484-1	WB-HNDLASSY
2	Compression a axiale	1	H-5484-SHAFT	WB-FRAME-PT2
3	Pompe À Huile	1	-----	WB-FRAME-PT3
4	Essieu, Roue Avant	1	H-5484-4	WB-FRAME-PT4
5	Anneau De Déflexion	1	-----	WB-FRAME-PT5
6	Anneau De Retenue D'orifice 95	1	H-5484-FPT6	WB-FRAME-PT6
7	Roulement 6012-2Rs	2	H-5484-7	WB-FRAME-PT7
8	Support Du Siège	1	-----	WB-FRAME-PT8

LISTE DES PIÈCES DU SCHÉMA DE LA STRUCTURE SUITE

#	DESCRIPTION	QTÉ	RÉF. ULINÉ	RÉF. DU FABRICANT
9	Anneau De Retenue De L'arbre 60	1	-----	WB-FRAME-PT9
10	Boulon À Tête Hexagonale M8 x 70	1	-----	WB-FRAME-PT10
11	Couvercle De Roulement	1	H-5484-FPT11	WB-FRAME-PT11
12	Plaque De Fixation	1	-----	WB-FRAME-PT12
13	Butées À Billes 51112	1	-----	WB-FRAME-PT13
14	Goupille À Ressort 5 x 28	22	H-5484-14	WB-FRAME-PT14
15	Écrou Freiné M8	1	-----	WB-FRAME-PT15
16	Vis À Tête Hexagonale M6 x 12	5	H-5484-16	WB-FRAME-PT16
17	Cadre De Transpalette	1	-----	WB-FRAME-PT17
18	Ensemble Du Bras De Bascule 685	1	-----	WB-FRAME-PT18
19	Roulement 6204-2Rs	12	H-1043-B9	B9
20	Grande Roue (Directrice)	2	H-5484-20	WB-FRAME-PT20
21	Ensemble De Matériel D'installation De La Grande Roue (Directrice) Comprend : • Demi-Cercle (4) • Rondelle (2) • Bague De Retenue Pour Essieu (2) • Couvercle Antipoussière (2)	1	H-7274	WB-FRAME-PT21 WB-FRAME-PT22 WB-FRAME-PT23 WB-FRAME-PT25
24	Goupille Cylindrique 16 x 42	2	H-5484-24	WB-FRAME-PT24
26	Bague 16 x 18 x 15	6	H-5484-26Q	WB-FRAME-PT26
27	Bague 16 x 18 x 20	2	-----	WB-FRAME-PT27
28	Bague 25 x 30	2	-----	WB-FRAME-PT28
29	Tête D'accouplement	2	H-5484-CH29Q	WB-FRAME-PT29
30	Goupille Cylindrique 16 x 44	2	H-5484-PR30Q	WB-FRAME-PT30
31	Arbre Long 685 (Sans Orifice)	1	-----	WB-FRAME-PT31
32	Anneau De Retenue D'orifice 25	2	-----	WB-FRAME-PT32
33	Biellette De Liaison 1220	2	H-5484-33	WB-FRAME-PT33
34	Goupille Cylindrique 16 x 100	2	H-5484-34	WB-FRAME-PT34
35	Goupille Cylindrique 20 x 158	2	H-5484-35	WB-FRAME-PT35
36	Bague 20 x 23 x 25	4	H-5484-36	WB-FRAME-PT36
37	Support De Roue (Niveau Inférieur)	2	H-5484-37	WB-FRAME-PT37
38	Bague 20 x 23 x 12	4	H-5484-38	WB-FRAME-PT38
39	Goupille Cylindrique 20 x 105	4	H-5484-PT39	WB-FRAME-PT39
40	Plaque De Support	4	H-5484-40	WB-FRAME-PT40
41	Anneau De Retenue D'orifice 47	8	H-5484-PT41	WB-FRAME-PT41
42	Roue (Porteuse) De Fourche	4	H-5484-42	WB-FRAME-PT42
43	Boulon À Tête Hexagonale M6 x 50	2	H-5484-PT43	WB-FRAME-PT43
44	Roue (Rouleau) D'entrée, Noir/Blanc	2	H-5484-PT44	WB-FRAME-PT44
45	Écrou Freiné M6	2	H-5484-PT45	WB-FRAME-PT45
46	Ensemble De La Roue Directrice	1	H-5484-SWA	WB-FRAME-PT2019

ULINE H-5484


TRANSPALETTE

ROBUSTE

1-800-295-5510
uline.ca

SCHÉMA DE LA POIGNÉE

A



LISTE DES PIÈCES DU SCHÉMA DE LA POIGNÉE

#	DESCRIPTION	QTÉ	RÉF. ULINÉ	RÉF. DU FABRICANT
A	Ensamble De La Poignée Comprend : • Axe Cylindrique #1 (1) • Cheville Ressort 3 x 20 #2 (1) • Roue De Pression #3 (1) • Bague 1220 #4 (1) • Unité De Tige De Traction #5 (1) • Bague Sf-1F2015 #6 (2) • Chaîne C-6-9-04A #7 (1)	1	H-5484-1	WB-HNDLASSY
1	Axe Cylindrique	1	H-5484-8	WB-HANDLE-PT8
2	Cheville Ressort 3 x 20	1	H-5484-9	WB-HANDLE-PT9
3	Roue De Pression	1	H-5484-10	WB-HANDLE-PT10
4	Bague 1220	1	H-5484-11	WB-HANDLE-PT11
5	Unité De Tige De Traction	1	H-5484-12	WB-HANDLE-PT12
6	Bague Sf-1F2015	2	H-5484-13	WB-HANDLE-PT13
7	Chaîne C-6-9-04A	1	H-5484-CHAIN	WB-HANDLE-PT14


ULINE H-5484

TRANSPALETTE

ROBUSTE

1-800-295-5510
uline.ca

SCHÉMA DE LA POMPE



Liste des pièces du schéma de la pompe

#	DESCRIPTION	QTÉ	RÉF. ULINE	RÉF. DU FABRICANT
1	Rondelle De Socle	1	H-5484-BWSHR	WB-PUMP-PT1
2	Coiffe De Ressort	1	H-5484-PT2	WB-PUMP-PT2
3	Ressort	1	H-5484-SPRNG	WB-PUMP-PT3
4	Anneau Antipoussière 18	1	H-5484-PT4	WB-PUMP-PT4

**TRANSPALETTE
ROBUSTE**

LISTE DES PIÈCES DU SCHÉMA DE LA POMPE SUITE

#	DESCRIPTION	QTÉ	RÉF. ULINE	RÉF. DU FABRICANT
5	Joint D'étanchéité De Type Y 18	1	H-5484-PT5	WB-PUMP-PT5
6	Anneau Antipoussière 45 x 57	1	H-5484-PT6	WB-PUMP-PT6
7	Anneau De Retenue D'orifice 58	1	H-5484-PT7	WB-PUMP-PT7
8	Joint Torique 58 x 3,55	1	H-5484-PT8	WB-PUMP-PT8
9	Joint Torique 45 x 3,55	1	H-5484-PT9	WB-PUMP-PT9
10	Couvercle De Guidage	1	H-5484-PT10Q	WB-PUMP-PT10
11	Manchon Du Tuyau	1	H-5484-PT11Q	WB-PUMP-PT11
12	Anneau De Guidage	1	H-5484-PT12Q	WB-PUMP-PT12
13	Joint D'étanchéité 45 x 55 x 7	1	-----	WB-PUMP-PT13
14	Piston 45 x 289,5	1	-----	WB-PUMP-PT14
15	Butée À Billes 51106	1	H-5484-PT15	WB-PUMP-PT15
16	Bouchon À Vis M10 x 1	2	H-5484-PT16	WB-PUMP-PT16
17	Rondelle 10	2	H-5484-PT17	WB-PUMP-PT17
18	Plaque De Levier	1	H-5484-18	WB-PUMP-PT18
19	Vis De Blocage À Fentes Avec Bout Pointu M6 x 25	1	H-5484-SLSCR	WB-PUMP-PT19
20	Écrou À Tête Hexagonale M6	1	H-5484-NUTM6	WB-PUMP-PT20
21	Joint Torique 10 x 2,65	1	H-5484-PT21	WB-PUMP-PT21
22	Ensemble De Goupille De Déclenchement	1	H-5484-PT22	WB-PUMP-PT22
23	Rondelle 20	2	H-5484-PT23	WB-PUMP-PT23
24	Goupille De Déclenchement	1	H-5484-PT24	WB-PUMP-PT24
25	Ressort 1,2 x 9,5 x 22	1	H-5484-PT25	WB-PUMP-PT25
26	Vis De Réglage De Pression M10 x 1	1	H-5484-PT26	WB-PUMP-PT26
27	Ressort 2 x 8 x 16	1	H-5484-PT27	WB-PUMP-PT27
28	Siège De Rotule	1	H-5484-PT28	WB-PUMP-PT28
29	Bille D'acier 5	1	H-5484-PT29	WB-PUMP-PT29
30	Tube D'essieu	1	H-5484-PT30Q	WB-PUMP-PT30
31	Vis À Tête Hexagonale M8 x 45	1	H-5484-PT31Q	WB-PUMP-PT31
32	Bille D'acier 7	1	H-5484-PT32	WB-PUMP-PT32
33	Joint Torique 10 x 2,65	1	H-5484-PT33	WB-PUMP-PT33
34	Appareil À Cartouches Iii	1	H-5484-PT34	WB-PUMP-PT34
35	Tige De Verrouillage	1	H-5484-PT36Q	WB-PUMP-PT35
36	Bague Composé 20 x 23 x 25	1	-----	WB-PUMP-PT37
37	Dessus De La Bille	1	H-5484-PT38	WB-PUMP-PT38
38	Axe Cylindrique 4 x 25	1	H-5484-PPT39	WB-PUMP-PT39
39	Ensemble Intérieur De Pompe À Double Vitesse	1	H-5484-DSPCA	WB-PUMP-PT40
40	Cylindre De Pompe À Double Vitesse	1	H-5484-PT40	WB-PUMP-PT41
41	Rondelle En Cuivre	1	H-5484-PMP41	WB-PUMP-PT42
	Ensemble De La Pompe (Non Illustré)	1	H-5484-PUMP	PUMPWB