


ULINE H-5048, H-6460
**INDUSTRIAL BACKPACK
VACUUM**

1-800-295-5510
uline.com



ROUTINE MAINTENANCE

DAILY

- Check Intercept® Micro Filter. Replace or empty if full.
- Check micro cloth filter. If dirty, rinse out and air dry before replacing back in vacuum.

BI-WEEKLY

- Inspect Hepa filters. Replace when discolored.

MONTHLY

- Check harness for fit and comfort. Replace lost or damaged pieces.

After 800 hours, send in to have carbon motor brushes replaced.

After 1,200 hours, send in to have carbon motor brushes replaced.

After 1,400 hours, send in to have carbon motor brushes replaced.